LUMINA 18

PROFESSIONAL LED WASH 14 X 15W

USER MANUAL

Please read the instructions carefully before use

ADASTRA

Lumina 18 LED 6-in-1 PAR Light

1. DMX512Control：10 Channel Model(A001)

CH	Display	Function
CH1	Dimmer	R、G、B、W dimmer : from dark to bright
CH2	R dimmer	R dimmer : from dark to bright
CH3	G dimmer	G dimmer : from dark to bright
CH4	B dimmer	B dimmer : from dark to bright
CH5	W dimmer	W dimmer: from dark to bright
CH6	Y dimmer	Y dimmer : from dark to bright
CH7	UV dimmer	UV dimmer: from dark to bright
CH8	Strobe	R、G、B、W、Y、UV strobe: from slow to fast
CH9	Function choice	0~50: DMX 1-6CH Control. 51~100: Different Colors Output 101~150: Colors Jump Change. 151~200: Colors Gradate. 201~250: Colors Pulse Change. 251~255: Sound-Active
CH10	Function speed	Speed function, from slow to fast

DMX512Control：6Channel Model(d001)

Channel	Function	Instruction
CH1	R Dimmer	Dimmer- Dark to Bright
CH2	G Dimmer	Dimmer- Dark to Bright
CH3	B Dimmer	Dimmer- Dark to Bright
CH4	W Dimmer	Dimmer- Dark to Bright
CH5	Y Dimmer	Dimmer- Dark to Bright
CH6	UV Dimmer	Dimmer- Dark to Bright

2. Nixie tube display menu description

No	Show	Function	Instruction
1	**A001**	DMX Address (001~512)	DMX-512 address set, 10 Channels mode
2	**d001**	DMX Address (001~512)	DMX-512 address set, 6 Channels mode
3	**r255**	Red (000~255)	UP、DOWN Change brightness
4	**G255**	Green (000~255)	UP、DOWN Change brightness
5	**b255**	Blue (000~255)	UP、DOWN Change brightness
6	**u255**	white (000~255)	UP、DOWN Change brightness
7	**Y255**	Amber (000~255)	UP、DOWN Change brightness
8	**l200**	Purple (000~255)	UP、DOWN Change the speed
9	**F000**	Strobe flash (000~255)	Strobe, slow to fast
10	**CC15**	Colors Jump Change (01~15)	Colorful jump, from slow to fast
11	**DE15**	Colors Gradate (01~15)	Colorful gradient, from slow to fast
12	**CP15**	Colors Pulse Change (01~99)	Colors Pulse, from slow to fast
13	**Soud**		Sound-Active